

---

**STEER SAFE, Inc.**

---

## **STEER SAFE STABILIZERS**

### **INSTALLATION INSTRUCTIONS**

**W-16 Figure 1**



- 1. BE SURE THAT WHEELS ARE IN STRAIGHT AHEAD POSITION BY MEASURING THE DISTANCE BETWEEN THE VEHICLE SPRING AND THE WHEEL ON BOTH SIDES.**
- 2. PLACE RIGHT AND LEFT WHEEL BRACKETS ON PROPER SIDES. LEFT SIDE IS DRIVERS SIDE.**
- 3. MOUNT WHEEL BRACKET TO STEERING KNUCKLE ARM BY PLACING WHEEL BRACKET OVER STEERING STOP BOLT, AND THEN START ½ INCH NUT.**
- 4. PLACE U-BOLT OVER STEERING ARM AND THROUGH U-BOLT HOLES IN WHEEL BRACKETS AND START NUTS.**
- 5. FIRST TIGHTEN ½ INCH NUT TIGHT. THEN TIGHTEN U-BOLT NUTS TIGHT.**

- 1. STEERING STOP BOLT**
- 2. STEERING ARM**
- 3. ½ INCH NUT**
- 4. U-BOLT**